

DPC 2-3

Installation and Operating Instructions

DPC 2-3 For Three Phase Dual Pumps up to 16A



SAFETY	4
INTRODUCTION	5
Applications	5
Features	5
Parameters & Specifications	6
INSTALLATION	7
Tools Used in Controller Installation	7
Controller Components	7
- LCD Screen	7
- Meaning Of The Icons Shown In The LCD	8
Installation – Drainage	10
- Terminals	10
- DIP Switch Settings	11
- Electrical Connections	12
Installation – Boosting	14
- Terminals	14
- DIP Switch Settings	14
- Electrical Connections	16
Installation – Water Transfer	19
- Terminals	19
- DIP Switch Settings	20
- Electrical Connections	21
OPERATION	23
Parameter Calibration	23
Erasing Former Parameters	24
- Erasing The Parameter Calibration	24
Switching to AUTO mode	24
Switching to MANUAL mode	25
Alarm Test	25
Pump Protection	25
Last Five Failure Records	25
Pump Accumulative Running Time	26
COMMUNICATION LINK	26
Basic Function	27
Special Application	27
Technical Parameters	27
TROUBLE SHOOTING	28

SAFETY

Following are the safety instructions which must be followed by the service partners or user while installing & operating the product. If ignored, physical injury or even death may happen. Read the safety instructions before handling the system.



WARNING

If these safety instructions are not observed, it may result in malfunction or damage to the equipment.

- All electrical connections must be carried out by skilled and qualified personnel.
- Never connect AC power to output U, V or W terminals.
- Ensure the motor, controller and power specifications are matching.



CAUTION

If these safety instructions are not observed, it may result in personal injury.

- Before carrying out any installation or maintenance operation, the controller must be disconnected from the power supply.
- Don't open the cover while the pump is running.
- Don't put wire, metal bar filament etc. into the controller.

NOTE (Notes or attention to ensure safe operation)

Important

- The manufacturer is not liable for malfunctioning if the product is not correctly installed, damaged, modified and/or put to run beyond the working range as given in this manual.
- The manufacturer reserves the right to make any modifications to this product from time to time.

INTRODUCTION

The digital Pump Controller model is easy to use, programmable controller and protection device for direct start with three phase two pumps with output power from 0.75kW – 7.5kW (1.5 - 16A) each.

The controller has many operation modes for adapting different pumping applications. Important features that distinguish the DPC Series Digital Pump Controllers from other controllers are the push button calibration for overload and the ability of dry run protection without float switches. It shows pump parameter, status and faults, etc.

APPLICATIONS:

The controller is useful in all cases where there is a need to control and protect two pump installations and managing the automatic operation by a variety of switching methods.

Typical applications:

- Water supply
- Irrigation
- Sewage
- Booster sets
- Rainwater reuse
- Stormwater

FEATURES:

- Built-in function switch for:
 - Drainage by liquid level control through float switches
 - Boosting water supply by pressure control through pressure switch and tank
 - Transfer of water by liquid level control through float switches
- Dry run protection without float switches
- Auto/ manual switch with screen lock in AUTO mode
- Dynamic LCD displaying for pump running status
- Protect the pump against many faults
- Push button calibration
- Pump accumulative run time
- Last five fault records
- RS485 communication (Modbus)
- Starts and stops the pump in accordance with liquid levels or pressure settings
- Pump shaft anti rust features

PARAMETERS AND SPECIFICATIONS:

Following chart shows the main technical parameters & specifications:


Main Technical Characteristics	
Control characteristic	Double liquid level control
	Pressure control
Working modes	Manual / auto
Drainage application	By using float switch
Pressure Boosting application	By using pressure switch
Water Transfer application	By using float switch
Main Technical Data	
Rated output power (amperes)	8 A, 12 A and 16 A
Rated input voltage	415 V
Trip response time of overload	5 sec - 5 min
Trip response time of open phase	< 2 sec
Trip response time short circuit	Less than 0.1 sec
Trip response time of under/over voltage	Less than 5 sec
Trip response time of dry run	6 sec (or this can be set manually)
Recovery time of overload	30 min (or this can be set manually)
Recovery time of under/over voltage	5 min
Recovery time of dry run	30 min (or this can be set manually)
Trip voltage of over voltage	115 % of rated input voltage
Trip voltage of under voltage	80 % of rated input voltage
PROTECTIONS COVERED	Dry run (without float/ probe)
	Overload (auto-calibrated or can be set)
	Transient surge
	Under voltage
	Over voltage
	Pump stalled
	Short circuit
	Phase loss (incoming & outgoing)
	Phase reversal
	Pump shaft anti rust protection
Other Technical Data	
Permissible ambient temperature	-5 to +50 deg C
Degree of protection	IP 55
Installation position	Vertical
Unit dimensions (L X W X H)	320 x 420 x 138 mm
Physical interface	RS485 bus interface: Asynchronous
Baud rate	1200, 2400, 4800, 9600 bps (default)
Protocol type	MODBUS protocol (RTU)

INSTALLATION


Please read this manual carefully before starting installation and operation. Any damage to the equipment caused due to failure to comply with the descriptions in this manual in installation or operation will be beyond the scope of the company's quality guarantee.

TOOLS USED IN CONTROLLER INSTALLATION:

Controller installation and wire installation will need the following tools, you also can choose the right tools according to your own experience.




Back view



Side view



wall
Mounting
clamp



ELECTRIC DRILL



CRIMPING PLIER




CROSS SCREWDRIVER

CONTROLLER COMPONENTS:

LCD SCREEN

Voltage Displaying Area



Ampere Displaying Area

Fault Displaying Area

Pump Running Status Displaying Area

MEANING OF THE ICONS SHOWN ON THE LCD:




The parameter configuration icon, when this icon appears, controller is in manual parameter adjustment mode.

Time displaying icon, when this icon appears, it mean controller is displaying some parameter of time, eg: pump dry run trip time(units: seconds).



Pump fault icon, when this icon appears, it means controller is displaying some fault condition.

Network connection error icon, when this icon appears, it means there is no network connection or network connection error between pump controller and computer/SCADA/BMS.



Network normal connection icon, when this icon appears, it means the network connection between pump controller and computer/SCADA/BMS.

Voltage

V

M

Minute

Second 

 Hour


Ampere 

 Percent

Pump running 

 Pump stopped

Low pressure or lack of pressure in the pipeline or pressure tank. 

 High pressure or full of pressure in the pipeline or pressure tank.

Pump A 


 Pump B

INSTALLATION - DRAINAGE:

Please read this manual carefully before starting installation and operation. Any damage to the equipment caused due to failure to comply with the descriptions in this manual in installation or operation will be beyond the scope of the company's quality guarantee.

TERMINALS

Using float switch



DANGER Electric shock risk.



Before carrying out any installation or maintenance operation, the controller should be disconnected from the power supply and the person should wait at least 2 minutes before opening the controller.



Never connect AC power to output U1 V1 W1 terminals.




Ensure the motor, controller, and power specifications match.




The electrical and hydraulic connections must be carried out by competent, skilled, qualified personnel.

DIP SWITCH SETTINGS

Users can set the function switch to suit different applications. Before setting the function switch, The unit should be disconnected from the power supply. After completing the settings of dip switches, Power may be applied to the unit. Following signs will be displayed in voltage displaying area on the LCD conforming to the following list:




Drainage Setting
Switches Down



Drainage Symbol

Connections for pump over temperature protection (where supplied with pump)





NOTE: To enable the pump's over temperature protection connect the pump's thermistor leads to terminals 14 and 15, 19 and 20 and remove the jumper.

If the pump is without thermistor switch, please use jumper to connect terminals 14 and 15, 19 and 20.

Do not run or lay the float switch wire, it must be inside the metal pipe. So, use PVC or PE tubing.

ELECTRICAL CONNECTIONS



Start Condition: Liquid level in the sump reaches float switch A (up) the controller will start the pump and the controller will alternate the pump on every start cycle.



Stop Condition: Liquid level in the sump is reaches low level (float switch A is down) the controller will stop the pump.

2nd Pump Start Condition: Liquid level in the sump reaches float switch B (up) the controller will run the second pump. Pumps run simultaneously until liquid level reaches low level (float switches A and B down).

Alarm Condition: While pumping, if the liquid level rises in the sump to high level (float switch C up), the controller will sound the alarm to warn the user to take further action.


Auto Antirust function: Under Auto mode, if controller observes that pumps didn't run for ten days then the controller will run the pump A for 3 seconds and stop, after 10 seconds interval, controller will run pump B for 3 seconds and stop. Auto antirust can prevent pump rusting and jamming of impeller due to pumps not running for a long time.

Meanings of the messages & graphic shown on the LCD screen

Messages & Graphics	
	Lack of water in sump
	Overflow in sump

INSTALLATION - BOOSTING:

TERMINALS



DANGER Electric shock risk.



Before carrying out any installation or maintenance operation, the controller should be disconnected from the power supply and the person should wait at least 2 minutes before opening the controller.



Never connect AC power to output U1 V1 W1 terminals.



Ensure the motor, controller and power specifications match.




The electrical and hydraulic connections must be carried out by competent, skilled, qualified personnel.


DIP SWITCH SETTINGS

Users can set the function switch to meet different applications. Before setting the function switch, the controller should be disconnected from the power supply.

After completing the setting, apply power to the controller and observe the application sign displayed on the LCD conforming to the BOOSTING symbol.




Boosting Setting
Switches UP



Boosting Symbol

Connections for pump over temperature protection (where supplied with pump)





NOTE: To enable the pump's over temperature protection, connect the pump's thermistor leads to terminals 14 and 15, 19 and 20 and remove the jumper.



If the pump is without thermistor switch, please use jumper to connect terminals 14 and 15, 19 and 20.

ELECTRICAL CONNECTIONS

WATER SUPPLY BY USING PRESSURE CONTROL THROUGH PRESSURE SWITCH



WATER SUPPLY BY PRESSURE CONTROL THROUGH PRESSURE SWITCH AND DRY RUN THROUGH FLOAT SWITCH







Normal Demand: When pressure in the pipeline is lower than the pressure switch B setting, controller will order single pump to run; pressure in the pipeline reaches the pressure switch B setting, single pump stops running; controller will alternate double pumps running automatically when pressure in the pipeline varies in the range of pressure switch B.

Extra Demand: When single pump is running, pressure in the pipeline still decrease to the pressure switch A setting, controller will give command to second pump to run simultaneously, till pressure in the pipeline reaches the pressure switch B setting, both pumps will not stop unless the pressure in the pipe line reaches the pressure switch A setting.



NOTE: Pressure Switch A = Low Pressure Switch, Pressure Switch B = High Pressure Switch.


Meanings of the messages & graphic shown on the LCD screen

Messages & Graphics	Description
	Low water level in source tank
	Enough water in source tank
	High pressure in pipeline or pressure tank
	Low pressure in pipeline or pressure tank





INSTALLATION - WATER TRANSFER:

TERMINALS

Using float switch




DANGER Electric shock risk.

-  Before carrying out any installation or maintenance operation, the controller should be disconnected from the power supply and one should wait at least 2 minutes before opening the controller.
-  Never connect AC power to output U1 V1 W1 terminals.
-  Ensure the motor, controller and power specifications.
-  The electrical and hydraulic connections must be carried out by competent, skilled, qualified personnel.


DIP SWITCH SETTINGS

Users can set the function switch to meet different applications. Before setting the function switch, the controller should be disconnected from the power supply.

After completing the setting, apply power to the controller and observe the application sign displayed on the LCD conforming to the TRANSFER symbol.




Transfer Setting



Transfer Symbol



Connections for pump over temperature protection (where supplied with pump)



NOTE: To enable the pump's over temperature protection connect the pump's thermistor leads to terminals 14 and 15, 19 and 20 and remove the jumper.





If the pump is without thermistor switch, please use jumper to connect terminals 14 and 15, 19 and 20.

ELECTRICAL CONNECTIONS



Normal Demand: when the liquid level in the overhead water storage tank is lower than (float switch A: Down), controller will order single pump to run; Liquid level reaches tank full level (float switch A: Up), pump stops running; controller will alternate both pumps on every start cycle.

Extra Demand: When single pump is running and liquid level is still decreasing to low level in overhead tank (Float Switch B: Down), controller will command second pump to run simultaneously, until liquid level reaches tank full level (Float Switch A & B: Up), both pumps will now stop.

Messages & Graphics	Description
	Low water level in source tank
	Enough water in source tank
	Low level in overhead tank
	Overhead tank full

OPERATION


BEFORE YOU START - Parameter calibration and erasing

To achieve best level of protection of the pump, it is essential that parameter calibration be done immediately after successful pump installation or pump maintenance.


PARAMETER CALIBRATION:

Pump/s must be able to pump water to enable correct calibration. If pumps are calibrated without water, overload and pump stalled errors may occur


1. Press the **MODE** key to switch to manual mode. If the controller is locked press **MODE** and **STORE** keys at the same time to unlock and go into manual mode. Make sure that the pump is not running, and LCD screen is displaying:



2. Press the **A START** key to run pump A, confirm the pump and all pipe network is in normal working state (including voltage, amps etc.) with LCD screen displaying:




3. Press the **A START** key. The controller makes a “beep” and a countdown starts with the LCD displaying: Controller now counts down from 8 seconds:



5. Pump A is ready for running.

4. The pump stops running and parameter calibration is completed with LCD displaying:




6. Press the **B START** key to repeat calibration for pump B. And follows the same procedure.

ERASING FORMER PARAMETERS:


When pump is reinstalled after maintenance or a new pump is installed, user must erase the former calibration and a new calibration must be done.

ERASING THE PARAMETER CALIBRATION:

1. Press the **MODE** key to switch to manual mode. If the controller is locked press **MODE** and **STORE** keys at the same time to unlock and go into manual mode. Make sure that the pump is not running and LCD screen is displaying:



2. Press the **A STOP** key for 3 seconds; the controller makes a “beep” sound, and the controller recovers the default factory setting and **A PUMP** no calibration flashing will appear in the LCD displays:



3. Repeat for pump B by using the **B STOP** key for 3 seconds.

SWITCHING TO AUTO MODE:

To switch between MANUAL and AUTO mode press **MODE** key. AUTO mode automatically locks controller. Under AUTO mode the controller will run or stop the pump according to the signal from the float switch.

NOTE:

- Under AUTO mode, if the pump is running and user wants to stop the pump, press the **MODE** key to switch to **MANUAL** mode and the pump stops.
- Under AUTO mode, if the input power is cut off and resumed, the controller will come into operating state after a 10 seconds countdown.
- No matter if the controller is **AUTO** or **MANUAL** state, if the input power is cut off and resumed again, the control panel will resume its operation in the same state as before the power being cut off.

SWITCH TO MANUAL MODE:

To switch between AUTO and MANUAL model press MODE and STORE keys at the same time to unlock and go into MANUAL mode. Press the START key to start the pump and the STOP key to stop the pump.

ALARM TEST:

Under MANUAL mode and pump/s not operating press STORE for 3 seconds to test the alarm.

PUMP PROTECTION:


During pump running, if dry run, overload, over voltage, etc. failures occur, the controller will immediately shut down the running pump and automatically execute a check for restarting conditions after a built-in time delay has elapsed. The controller will not recover automatically until all the abnormal situations have been cleared. If pump stalled, open phase or other serious failure has occurred, pump user must immediately check pump and motor.

LAST FIVE FAILURE RECORD:

The control panel can memorize the last five failures of pump, so it is very convenient for the users to analyze the pump running conditions.


DISPLAYING THE LAST FIVE:

1. Press the **MODE** key to switch to MANUAL mode, make sure the pump is not running and the LCD screen is displaying:



2. Press and hold **A STOP** key and **MODE** key, the controller makes a “beep” sound and displays pump A failure record.

3. Press the **A STOP** key to quit the failure record display:




NOTE: The failure displayed above is PUMP STALLED. Repeat for pump B by using B STOP key.

PUMP ACCUMLATIVE RUNNING TIME:


The controller can memorize how many hours that pump has run, so it is very convenient for the pump user to analyze the pump running conditions and do maintenance.

DISPLAYING THE PUMP ACCUMLATIVE RUNNING TIME:

1. Press the **MODE** key to switch to manual mode, make sure that the pump is not running and the LCD screen is displaying:



2. Press and hold the **STORE** key and **A STOP** key. The controller makes a “beep” sound and displays the accumulative run time. The pump has run for 23 hours.



3. Press the **A STOP** key to quit the accumulative running time display.

4. Repeat for pump B by using B STOP key.

COMMUNICATION LINK

The controller has communication interface, between the pump controller and computer/SCADA/BMS, users can realize a long-distance monitoring function.

This function applies to where the controller is installed in the basement or pumping room, but users require to monitor and control the pump on the ground or in a control room.

BASIC FUNCTION:

Computer/SCADA/BMS (Optional) with communication interface can realize long distance monitoring. In the control room, users can realize all the functions of the master controller through the slave controller, except parameter calibration and adjusting.

SPECIAL APPLICATION:


As adopting communication interface, the communication distance through wire is less than 1200 meters. whereas for a longer communication distance like mine, water tower, across railway road and bridge etc., users can adopt RS485 extender.

TECHNICAL PARAMETER:

The following chart shows main technical parameters of communication between the pump controller and Computer/SCADA/BMS.

Main Technical Data	
Physical interface	RS485 Bus Interface: asynchronous semi duplex
Data format	1 start bit, 8 data bit, 1 stop bit, no verify
	1 start bit, 8 data bit, 2 stop bit, no verify
	Default: 1 start bit, 8 data bit, 1 stop bit, no verify
Baud rate	1200,2400,4800,9600 bps (default 9600bps)
	Setting range of controller address: 1-126
	127: broadcast address, host computer broadcasting, slave machine response forbidden
Protocol type	MODBUS protocol (RTU)
Rated input voltage for SC	AC 240V/50Hz, single phase
Main Installation Data	
Wire communication distance	1200 meters max by shield twisted pair cable (STP) for RS485 & CAN
	5000 meters max by shield twisted pair cable (STP) and RS485 extender
STP	STP-120U one pair 20AWG for RS485 & CAN
RS485 extender	5000 meters (9600bps)

TROUBLE SHOOTING GUIDE

Fault message	Possible cause	Solutions
Flashing of UNDER V	The real running voltage is lower than the set voltage, pump is in under voltage protection state.	Report low line voltage to the power supply company.
		Control will attempt to restart the pump every 5 min until line voltage is restored to normal.
Flashing of OVER V	The real running voltage is higher than the set voltage, pump is in over voltage protection state.	Report high line voltage to the power supply company.
		Controller will attempt to restart the pump every 5 min until line voltage is restored to normal.
Flashing of OVERLOAD	The real running ampere is higher than the calibrated/set running ampere, pump is in overload protection	Controller will attempt to restart the pump every 30 min until running ampere is restored to normal.
		Inspect pump and motor winding.
Flashing of PUMP NO CALIBRATION	Parameter calibration not completed.	Refer to parameter calibration setting.
Flashing of DRY RUN	Liquid level in the well/ sump is below the pump intake, pump stops running.	Controller will attempt to restart the pump every 30 min until liquid level is above the pump.
Flashing of PUMP STALLED	Pump running amps exceeded normal run amps by more than 200%.	Cut off power supply and repair or replace pump.
Flashing of REPEATED START	Pump starts more than 5 times per minute.	<ul style="list-style-type: none"> ▪ Check pressure tank pre charge ▪ Check pressure tank bladder ▪ Check pressure switch settings ▪ Check pressure switch for defects.
 <p>ON LINE</p>	No communication link between SC / computer and control.	Connect the control to SC / computer to realize long distance monitoring.

GRUNDFOS SOUTH AFRICA (PTY) LTD

16 Laschelles Road, Meadowbrook
Germiston
South Africa
Tel. +27 10 248 6000
rfqssa@sales.grundfos.com
www.grundfos.com/za

GRUNDFOS KENYA LTD.

Funzi Road, Industrial area,
Nairobi, Kenya
Tel. +254 709 048 000
rfqssa@sales.grundfos.com
www.grundfos.com/ke

GRUNDFOS PUMPS GHANA LTD

10 Lilongwe Avenue,
East Legon Accra,
Ghana
Tel. +233 302 540 172
rfqssa@sales.grundfos.com
www.grundfos.com/gh