

Grundfos Connect Asset Monitor

Features

Subscription types	Lite Free monitoring	Notify	Essential	Professional
 Devices per gateway	1	1	1	Up to 3*
 Notifications and alarm management	Email	Email/SMS	Email	Email/SMS
 Alarms and warnings <ul style="list-style-type: none"> Basic: Alarm and warning Full: Alarm and warning codes including descriptions, remedies, acknowledgment log, etc. 	 Basic	 Full	 Full	 Full
 User management and audit log <ul style="list-style-type: none"> Create and manage users including rights and access levels and track user changes 				
 Monitoring (last received values) <ul style="list-style-type: none"> Operation, control mode and related setpoints Product data 				
 Remote control <ul style="list-style-type: none"> Change duty point and start/stop system, control mode and start/stop individual pumps 				
 Trend data <ul style="list-style-type: none"> Basic: Pre-defined trends e.g. temperature, head, flow, speed, energy start/stops, etc. Full: Fully customisable 			 Basic	 Full
 Report and export <ul style="list-style-type: none"> Extract data for reporting as a PDF or spreadsheet and set up recurring reports 				
 Customisable dashboards <ul style="list-style-type: none"> Add widgets and tailor your dashboards Add application images with custom data points, etc. 				
 Cloud alarms <ul style="list-style-type: none"> Set up threshold alarms for data points 				
 File storage <ul style="list-style-type: none"> Store documents, pictures, repots, etc. 				

* Up to three devices per gateway (e.g. MPC, LC, MAGNA, etc.)

GRUNDFOS 

Possibility in every drop